

NEMS and Nano fabrication for bio-applications

Beomjoon KIM, Associate Professor

Center for International Research on Micro Mechatronics (CIRMM)
Institute of Industrial Science
The University of Tokyo




LIMMS Research Coverage

Since its creation (1995) :
MICRO & NANOTECHNOLOGY



NOWADAYS : 3 research axes








- **New NANOTECHNOLOGIES** (process and characterization)
- **ADVANCED INTEGRATION** of MEMS & NEMS functions
- **Micro and nanotech applied to the BIOLOGY**

1993-1998 東京大学精密機械工学専攻、生産技術研究所 増沢研 修士/博士

マイクロ放電加工

WEDG: Wire Electro Discharge Grinding








細穴の内部形状の測定

AFM/STM Like ?

A microhole in quartz glass machined by USM (ultrasonic machining)



GOAL: To achieve Low-cost, high performances
(high sensitivity, integrated functions, etc.) Bio-sensors

Top down:

- * Shadow mask patterning
- * Electro-spray deposition
- * Electroplating with AAO nano porous membranes

Bottom up:



- * Micro/nano contact printing with SAM
- * liquid μ CP and R2R micro CP
- * Optical soft-lithography for 3D micro pattern

Nano fabrication technology:



To develop **unconventional Nano lithography** & nano fabrications with low-cost, larger area even in 3D curved surfaces

Unconventional Nano fabrication

Mix and Match Unconventional Nano patterning technology





Micro
contact
printing




Array of 30nm wide nanowire

Print
based





- Development of (1) **unconventional micro/nano patterning**
of (2) **novel micro/ nano probes**
for bio-MEMS device/Single cell/singular molecule sensing device
(1) 広面積、新規ナノパターニング技術の開発(ソフトリソグラフィー、プローブリソ、シャドウパターン)
(2) バイオ物質(細胞、たんぱく質、DNAなど)の計測デバイスの開発

Biology application






Micro Contact printed
F1-ATPase protein

μCPを用いたF1-ATPaseの



SEM of protein deposited protein film
and cantilever


Polymer cantilever biosensor using
electrospray deposition of proteins
(α -lactalbumin IgG patterned, cross-linked by glutaraldehyde
vapor, co-work@RIKEN)




SAM表面処理法を用いた生体細胞のパターニング

Fabrication of Micro Structures on Convex/Concave Substrates


Fabrication Process of PDMS Photomask and Optical Softlithograph



Fabrication process for PDMS flexible photomask



Fabrication process for SU-8 structures on convex substrates



GOAL: To achieve Low-cost, high performances
(high sensitivity, integrated functions, etc.) Bio-sensors

Nano wires :

- 1> Nanowire heater fast, local temperature control (bio-thermal appl.)
- 2> CMOS-compatible Si FET nanowire sensor (for biosensing)
- 3> Surface phonon polaritons heat transfer

Top down:

2011 Journal list

J. Micromech. Microeng.
Lap on a Chip

Bottom up:

Micro/nano contact printing with SAM

liquid μ CP and R2R micro CP

Optical soft-lithography for 3D micro pattern

nano porous membranes

Nano fabrication technology:



To develop **unconventional Nano lithography** & nano fabrications with low-cost, larger area even in 3D curved surfaces

Previous work:



Temperature mapping with Ni nanowire & Rhodamine B

1. Capture fluorescent images:

a) Reference image - I_{Ref}




b) Image of heated structure - I_{Heated}



2. Normalization of intensity changes:


$I_{\text{Heated}}/I_{\text{Ref}}$



T (Intensity)



3. Conversion to temperature

Temperature ($^{\circ}\text{C}$)




Cell heating and HSP-expression result

Patrick et al. Lab Chip (2011)



Cell models at the same position as cells expressing GFP




- Heat-shock happened in a range **42-44 °C** predictable from current literature
- Accuracy of our method : **± 1 °C**
- **High confinement** of heat-shock possible

Non-conventional fabrication of field-effect transistor silicon nanowire based label-free biosensors


P. Ginet, S. Akiyama, H. Fujita and B.J. Kim
Institute of Industrial Science, The University of Tokyo

Silicon nanowires : FET functionalization




- A top-gate gold electrode is used to address individually each NW array and to avoid the high voltages required for backside type gate electrodes

タンパク質のセンシング




ゲート電圧 -1V から 0V の範囲内でタンパク質の検出が可能



ゲート電圧 -0.3V
 $\Delta S/S = 20\%$

他の研究例との比較

0.3 ng/mL Streptavidin のセンシング





$\Delta S/S = 3\%$

G. Zheng et al., *Nature biotechnology*, 2005


- ☐ $pI_{\text{streptavidin}} > pH_{\text{BHF } 0.01x}$
- ☐ clear detection of streptavidin at 1 $\mu\text{g/mL}$
- ☐ weak but reproducible detection at 0.1 $\mu\text{g/mL}$

Real Hot Topics at this moment

- Micro heaters chamber device → **Supramolecular interaction between biomolecules and calixerenes capped Silver nanoparticles**. Study of the mechanism of aggregation and the effect on the plasmonic resonance, nucleotides




Bulky calixarene ligands prevent gold nanoparticles from aggregating yet leave much of the particles' metal surface accessible for small-molecule catalysis.




2011, *Chemical Science*,
IEEE *NEMS* submitted

- New investigation of thermal conductance in nanostructures → **Surface phonon polaritons Heat transfer enhancement ? abnormal heat conduction phenomena related to ballistic regimes of transport**. Design by modeling a micro/nano structure that allows for strongly enhancing the coupling between SPPs. Experimental works to prove their contribution to heat conduction.



2010-2012, 科研基盤B

CIRMM/Institute of Industrial Science,



GOAL: To achieve Low-cost, high performances
(high sensitivity, integrated functions, etc.) Bio-sensors

Nano channel/fluidics :

- 1> Single DNA molecule's mobility investigation
- 2> Long DNA separation in nano fluidic devices

Nano wires :

- 1> Nanowire heater fast, local temperature control
- 2> CMOS-compatible Si FET nanowire sensor (for biosensing)
- 3> Surface phonon polaritons heat transfer

Top down:

- * Shadow mask patterning
- * Electro-spray deposition
- * Electroplating with AAO nano porous membranes

Bottom up:

- * Micro/nano contact printing with SAM
- * liquid μ CP and R2R micro CP
- * Optical soft-lithography for 3D micro pattern

Nano fabrication technology:

To develop **unconventional Nano lithography** & nano fabrications with low-cost, larger area even in 3D curved surfaces

NOT Published YET


The 2nd stage ;

*DNA electrophoresis ~~under pressure gradient in~~
nanoslits device*

*LONG DNA separation success!
- Length dependant mobility*


‘Shadow evaporation’ to achieve the device scale to deform DNA.

Conventional UV lithography *cannot easily fabricate the relevant scale* for DNA confinement.




'Anisotropic etching' of zigzag pattern to achieve the repetitive deformation of DNA.

The alternating structure of wide and narrow parts can be fabricated by parallel at ONE TIME process.





The length dependent mobility in chamber-channel type device


The large T4-DNA is slower than the small λ -DNA.



in 200-nm wide chamber-channel
 $E = 5 \text{ volt / cm}$ 10 μm



- Practical Point-of care & disposable bio-sensor chip (interface with electrical signals).
- “Chip in a Lab”-> Smart Portable “Lap on a Chip”





Lap

**MEMS/NEMS
for bio-applications?**

Chip in a Lab

*Point of Care
Portable Chip!*

on a Chip




lsi.epfl.ch

Biosensors:

Needs: micro fluidics
micro pump,
valves, etc.



Key: interface sensor




1. Twin Microcantilever Type Sensor Arrays for electrical/physical characterization of single cell

単一細胞(特に、赤血球)の電気・物理的特性を測るMEMSデバイスの開発


Y.H. Cho et al., *J. of MEMS* (2006)




Impedance magnitudes of air, DI water, PBS, normal RBC, and abnormal RBC



To outlet channel






Average impedance value for normal and abnormal RBC through the same device (7 times/each cell)





Fabrication Results

2. Single-cell Electroporation Microchip with Three Dimensional Si Microelectrodes for Gene Transfection

単一細胞のエレクトロポレーション用マイクロチップの開発と分析



Simulation results of electric field around microcantilever electrodes
(Max $\approx 3 \times 10^4$ V/m)



- ◆ Experimental conditions
- Jurkat (T-lymphocyte) cells
- Waveform generator (Tabor Electronics Ltd.)
- Pulse duration: 100 ms
- Pulse period: 1 ms
- Pulse sequence: 10 times
- Applied voltage: 0.7
- Fluorescence: GFP, trypan blue

Expression of GFP after 44 hours